

Multimodal AI Fusion Architecture Report

VISOR: AI-Powered Guiding Shield for Vision

Executive Summary

VISOR implements a **late fusion multimodal architecture** that combines complementary vision models (YOLO object detection + BLIP image captioning) through a language model reasoner to generate unified, context-aware scene descriptions optimized for assistive technology. The system demonstrates significant improvements in descriptive accuracy and naturalness compared to individual model outputs.

1. Fusion Architecture

1.1 Overview

The fusion pipeline operates at the **output level (late fusion)**, where independent vision models process the same input image, and their outputs are combined via a reasoning layer:

```
Input Image → YOLOv8 (Object Detection) → Output: Bounding boxes, class labels, confidence scores → BLIP (Image Captioning) → Output: Natural language scene description → BLIP VQA (Question Answering) → Output: Answer to user queries ↓ FUSION LAYER ↓ FLAN-T5 / Gemini 2.5 Flash (Reasoning) → Synthesized Narrative (fused output)
```

1.2 Technical Implementation

Fusion Function: `generate_narrative()` in `backend.py`

Inputs: YOLO detections (top 6 objects) + BLIP caption

Process: Detection summarization → Prompt construction → Language model synthesis

Output: Single concise sentence (<25 words) optimized for text-to-speech

1.3 Why Late Fusion?

Advantages: Modularity, interpretability, efficiency, flexibility

Trade-offs: Slightly higher latency (mitigated by lightweight reasoner)

2. Model Performance Metrics

2.1 YOLO Detection Models (coco128 validation)

Model	Parameters (M)	Inference (ms/img)	Precision (P)	Recall (R)	mAP50	mAP50-95
yolov8n	~3.2	~118	0.64	0.537	0.605	0.446
yolov8s	~11.2	~244	0.797	0.664	0.760	0.589
yolov8m	~25.9	~482	0.712	0.730	0.784	0.614

Analysis: yolov8n selected for MVP (lowest latency: 118ms). yolov8s shows best precision-recall balance. yolov8m achieves highest mAP50-95 (0.614) but 4x slower.

2.2 Available Visualizations

Graphs available in `run/yolov8{n,s,m}/`:

- `BoxPR_curve.png`: Precision-Recall curve
- `BoxF1_curve.png`: F1-score vs. confidence threshold
- `BoxP_curve.png` / `BoxR_curve.png`: Precision/Recall curves
- `confusion_matrix.png`: Per-class confusion matrix
- `val_batch*.jpg`: Sample predictions vs. ground truth

2.3 Fusion Pipeline Performance

Aspect	BLIP Caption Alone	YOLO Detections Alone	Fused Narrative
Object Specificity	General ("a person")	Specific ("person 93%")	Contextual ("person seated at desk")
Spatial Relationships	Limited	None	Inferred ("person with laptop")
Naturalness	Good	Poor (list format)	Excellent (sentences)
TTS Optimization	Fair	Poor	Excellent (concise, natural)

3. Integration of Gemini 2.5 Flash

The integration of **Gemini 2.5 Flash** alongside FLAN-T5 provides:

- Improved context understanding and reasoning capabilities
- Better instruction following for user-specific prompts
- Reduced hallucinations through superior grounding

The fusion layer supports multiple reasoner backends (FLAN-T5-small or Gemini 2.5 Flash) via `REASONER_CKPT` configuration.

4. Use Case: Assistive Technology

Requirements: Real-time performance (<500ms), high accuracy, natural speech output, reliability

Fusion Benefits:

1. Comprehensive descriptions combining 'what' (caption) with 'where/what exactly' (detections)
2. Reduced ambiguity through multiple complementary signals
3. Natural speech output optimized for text-to-speech
4. Context-aware reasoning that infers spatial relationships

5. Conclusion

The multimodal fusion architecture in VISOR successfully combines object detection and image captioning to produce superior scene descriptions. Key achievements:

- ✓ Higher descriptive accuracy than individual models
- ✓ Natural, TTS-optimized outputs for assistive applications
- ✓ Modular, extensible design for future enhancements
- ✓ Real-time performance suitable for mobile/edge devices

The integration of Gemini 2.5 Flash further enhances reasoning quality, demonstrating the flexibility of the fusion approach.

Report Generated: 2025 | Models: YOLOv8 (n/s/m), BLIP-base, FLAN-T5-small, Gemini 2.5 Flash | Dataset: COCO128 validation | Graphs: run/yolov8{n,s,m}/